


Model No. 4044

LIGHTBOLTPLUS

**Twin Retractable Worklight &
Spotlight with RED FLashing LEDs**

Instruction Manual



MobilePower, LLC • Bluffton, SC 29909

www.Mobilpower-us.com

Office: (800) 708-8550

customerservice@mobilepower-us.com



LIGHTBOLT 2 ITEM #4044 EXTENDABLE WORK LIGHT

BEFORE YOU USE THIS DEVICE FOR THE FIRST TIME, PLEASE READ THE FOLLOWING NOTES IN THIS MANUAL AND HEED ALL WARNINGS, EVEN IF YOU ARE FAMILIAR WITH HANDLING ELECTRONIC DEVICES. KEEP THIS MANUAL IN A SAFE PLACE FOR FUTURE REFERENCE.

WARNING

To prevent serious injury or damage:

- Keep dry. DO NOT open, drop, short-circuit, incinerate, expose temperatures higher than 140°F, or change /use if damaged.
- Only use the Charging Adaptors provided with the Work Light. Use of any other adaptors may damage the tool or result in a fire.
- Do not submerge in water or any other liquid. It is not waterproof.
- Do not operate in explosive atmospheres, such as in the presence of flammable liquids, gases or dust.
- Do not charge the Work Light more than 8 hours. Overcharging will cause overheating and shorten battery life.
- Read warnings on the package before use.

PRODUCT DESCRIPTION

Your new cordless rechargeable Extendable Work Light provides a safe and portable source of light when and where you need it. It is not waterproof and prolonged use in the rain or snow should be avoided.

It is ideal to use during automotive repair work, roadside emergencies, work around the home, camping, or during power failures.

Power Requirements: 6V DC 500mA

Battery Type: Internal, Rechargeable, Lithium-ion

Battery Pack: 3.7V 1100mAh

Bulb Type: White LED

LED Life: 100,000 Hours

RUNNING TIME

The approximate running times for this light when the battery is fully charged and at maximum performance level are as follows:

30 LED WORK LIGHT: Up to 3 Hours

1W LED: Up to 2 Hours

RED FLASHING LEDs: Up to 40 Hours.

MAGNETIC BASE

The Extendable Work Light features a magnetic base with a soft coating on the bottom, allowing the light to be attached to a vehicle or other metal objects without damaging or scratching the painted surface.

NOTE

Do not place the light on or near computer equipment, computer disks or other types of magnetic storage equipment as strong magnetic fields can erase or corrupt data.

OPERATION MODES

THIS EXTENDABLE WORK LIGHT FEATURES TWO DIFFERENT LAMPS. YOU CAN SELECT THE SUITABLE LIGHT OPERATION MODE FOR EACH APPLICATION.


1. FLOODLIGHT MODE: Hold the light by its body and pull the lens section upwards to open the lantern and turn on the LED switch (position I) The Extendable Work Light can be operated as a floodlight using 30 LEDs for maximum illumination. Operating time in this mode is at least 3 hours on a full charge. Do not look directly at the light when using the floodlight.

2. SPOTLIGHT MODE: Press the ON switch Position (I). In this mode the Extendable Work Light operates as a spotlight using 1W LED, this gives a powerful focused light with a maximum operating time of at least 2 hours on a full charge.

3. RATCHETING HEAD LIGHT FUNCTION: The head light of your unit can adjust up and down. To operate the tilting head of your Lightbolt Plus, press the release button shown as 'Swivel Head Switch' in the diagram below. The head of your light will adjust up to 90 degrees.

4. ROTATING HEAD LIGHT FUNCTION: The head of your Lightbolt Plus can also swivel to aim where needed. To operate the swivel function, turn the head light section of your Lightbolt Plus left or right.

5. EMERGENCY RED FLASHER: Your Lightbolt Plus features a red LED emergency flasher. To operate, push the spotlight on/off switch TWICE. To turn off, push the button again.



CHARGING INSTRUCTIONS

THE EXTENDABLE WORK LIGHT MUST BE FULLY CHARGED BEFORE BEING USED FOR THE FIRST TIME. IT IS RECOMMENDED THAT THE BATTERY BE RE-CHARGED EVERY 3 MONTHS TO ENSURE MAXIMUM PERFORMANCE IN AN EMERGENCY.

This will ensure that the battery gives its best performance now and on future re-charging cycles. The AC and DC charging adapters are for re-charging the battery only. They cannot be used to directly power the light. Always ensure that the light switch is in the OFF position while charging.

USING THE AC CHARGING ADAPTER

1. Stand the light vertically on its base. Plug the AC charger into the charging port on the base of the light next to the charging indicator lamp.
2. Plug the adapter into a 120V outlet and switch on the outlet (if applicable).

3. The charging indicator lamp will glow RED while charging is in progress.

4. The battery will be fully charged after approximately 3-5 hours, and the RED charging indicator will turn to GREEN when the unit is fully charged. Disconnect the AC charger from the light, remove the adapter from the wall socket or switch off.

TO PREVENT OVERHEATING DO NOT CHARGE FOR MORE THAN 8 HRS.

SAFETY PRECAUTIONS

Use the 120V AC charging adapter indoors in a dry location only. Exposure to damp or wet conditions could cause a shock or damage to the adapter.

Do not use the charger near flammable liquids or materials.

Store in dry location and do not allow the charging adapter to come in contact with water, rain or snow.

If the charging adapter comes into contact with water, place in a dry location at room

temperature, on a soft absorbent towel and allow to dry thoroughly.

Do not operate the unit until it is completely free of moisture.

Use only the AC charging adapter supplied with light. Do not attempt to charge the light with an adapter that is not compatible as this could result in a fire, damage to the light or personal injury.

The AC CHARGING ADAPTER complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

USING THE DC CHARGING ADAPTER

1. Stand the light vertically on its base. Plug the adapters jack plug into the socket on the base of the light next to the charging indicator lamp.
2. Plug the adapter into the vehicle's 12V DC cigarette lighter or accessory power socket.
3. The charging indicator lamp will glow RED while charging is in process.
4. The battery will be fully charged after approximately 3-5 hours, and the RED charging indicator will turn GREEN when the unit is fully charged.
5. Disconnect the jack plug from the light, and remove the DC adapter from the 12VDC socket.

TO PREVENT OVERHEATING DO NOT CHARGE FOR MORE THAN 8 HRS.

SAFETY PRECAUTIONS

The DC charging adapter can be used in most vehicles by plugging into the 12V DC cigarette lighter or accessory power socket.

Store in dry location and do not allow the charging adapter to come in contact with water, rain or snow.

If the charging adapter comes into contact with water, place in a dry location at room temperature. on a soft absorbent towel and allow to dry thoroughly.

Do not operate the unit until it is completely free of moisture.

Use only the DC charging adapter supplied with this light. Do not attempt to charge the light with an adapter that is not compatible as this could result a fire, damage to the light or personal injury.

CARE AND MAINTENANCE STORAGE

Store the Extendable Work Light and charging adapters in a clean and dry area. Be sure to keep the charging adapters supplied with this product stored separately from similar items as only charging adapters included with this light are compatible. Using a non-compatible charger could cause damage to the light or personal injury.

The work light may also be stored in a vehicle for use in roadside emergencies. To prevent the light and any of the accessories being damaged, please ensure that it is properly secure and in a safe place inside the vehicle.

CLEANING

All exterior surfaces of the Extendable Work Light can be wiped clean with a soft cloth dampened with a mild soap and water solution. Do not immerse or submerge any part of light in water or any other solvent. Never use solvents or cleaning agents containing petroleum (petrol, kerosene, oil), paint thinner, turpentine, alcohol, or ammonia. Harsh materials like these can damage surfaces.

MAINTENANCE

Only qualified service personnel must perform repairs. Do not open the exterior casing of the Extendable Work Light as there are no user serviceable parts inside. Opening or visible attempts to open or repair a light may void any guarantee and / or cause damage to the

product or personal injury. LED bulbs will never wear out under normal conditions and do not need to be replaced. Rechargeable battery pack cannot be replaced.

This product contains an internal Lithium-ion battery pack for formulated from environmentally sensitive materials. This product must be disposed of properly with due care for the environment. Please return this product to your local dealer or to your local recycling station where batteries will be recycled or disposed of properly.



MobilePower, LLC. Warrants to the original purchaser that the this portable lighting unit shall be free from defects in material and workmanship for a period of one year from the original date of purchase. If the product is determined by MobilePower, LLC to be defective in material and workmanship during the warranty period MobilePower, LLC will repair or replace the defective product or defective accessories/components with factory original specification product at its option. The original purchaser is authorized to obtain this warranty with the proof of purchase within the warranty period. To obtain shipping instructions related to the warranty services in North America visit us at www.mobilepower-us.com, call 800-708-8550 Customer Support or contact us at customerservice@mobilepower-us.com.

You may ship the defective product with freight prepaid to MobilePower, LLC. Your replacement will be shipped back to you at no additional charge.

Great care must be taken when packing the product and all associated accessories into a suitable packing box along with the original dated purchase receipt or invoice. The package must include a letter stating the defect details, contact information including physical address. Any address with a PO Box will not be processed and will be held until further notification from the consumer.

Make certain that your package can be tracked when you are shipping the defective products to us. MobilePower, LLC will not be responsible for lost packages sent by consumers. MobilePower, LLC. Will not be responsible for damages incurred during shipment to our facilities. Failure to provide the original purchase receipt or proof of purchase will render this warranty invalid.

THIS WARRANTY SHALL NOT APPLY IF THIS PRODUCT IS:

(A) DAMAGED RESULTING FROM ABUSE, MISUSE, NEGLIGENCE, ACCIDENT, LACK OF MAINTENANCE, ABNORMAL WEAR AND TEAR, UNREASONABLE USE OR BY OTHER CAUSES UNRELATED TO DEFECTIVE MATERIAL OR WORKMANSHIP (B) IS USED FOR COMMERCIAL PURPOSES; (D) IF THE PRODUCT HAS BEEN SUBJECTED TO WATER OR FIRE.

This warranty provides you with specific legal rights, and you may also have other rights which vary from state to state.

This warranty is valid only in North America.

MobilePower, LLC. Bluffton, SC 29910
www.mobilepower-us.com
Customer Support: (800) 708-8550
Customerservice@mobilepower-us.com