

# KEURIG®

## HyperChiller®

### ICED COFFEE CHILLER

#### QUICK START GUIDE

Please read all instructions carefully before use and keep for future reference.

**Have questions?** We're here to help. Visit [Keurig.com/Hyperchiller](http://Keurig.com/Hyperchiller) for additional product and warranty information.

**Still need help?** Give us a call at 1-866-901-BREW (2739).



**LIMITED  
1-YEAR  
WARRANTY**

## IMPORTANT SAFEGUARDS

Keurig® and Hyperchiller® brands take safety very seriously. This product is designed and manufactured with our valued consumers' safety in mind. Please save these instructions. Fits with all At Home Keurig® Brewers (except K-15, K-mini® and K-Express® brewers).

## PARTS IDENTIFICATION



1. Lid
2. Small stainless steel cup
3. Large stainless steel cup
4. Outer plastic cup

**NOTE:** The small stainless steel cup nests inside the large stainless steel cup. Both cups can be attached and detached from the lid by twisting.

**IMPORTANT: WASH BEFORE USE (Top shelf dishwasher safe)**

## ASSEMBLY INSTRUCTIONS



1. Fill small stainless steel cup with water to MAX fill line and twist on lid.
2. Fill large stainless steel cup with water to MAX fill line and pour into outer plastic cup.
3. Twist the large (empty) stainless steel cup onto the lid.
4. Twist the outer plastic cup with the assembly from Step 3.

**5. Place upright in your freezer until frozen solid (minimum of 12 hrs) and your Keurig® Hyperchiller® is now ready to use!**

ST0000000482 REV A; AW0000000569 REV A

# KEURIG

## HyperChiller®

### ICED COFFEE CHILLER

#### USE AND CARE GUIDE

Get the most from your new Keurig® HyperChiller®



#### HYPERCHILLER® COOLING TIMES

Coffee Size	Swirling	Resting
Small* (6 oz)	60 seconds	2 minutes
Medium* (8 oz)	60 seconds	2 minutes
Large* (10 oz)	60 seconds	3 minutes
Extra Large* (12 oz)	60 seconds	3 minutes

\*These are approximate cooling times. Swirling your HyperChiller® after brewing will cool your coffee within 60 seconds in most brew sizes!

#### GENERAL INFORMATION

Periodically, the product should be taken apart and thoroughly washed. All parts are top-shelf dishwasher safe.

For a demo video of product assembly & use, go to: [keurig.com/hyperchiller](http://keurig.com/hyperchiller)

#### IMPORTANT SAFEGUARDS

Keurig® and HyperChiller® brands take safety very seriously. This product is designed and manufactured with our valued consumers' safety in mind. Please save these instructions. Fits with all At Home Keurig® brewers (except K-15, K-Mini®, and K-Express® brewers).

#### PARTS IDENTIFICATION



1. Lid
2. Small stainless steel cup
3. Large stainless steel cup
4. Outer plastic cup

**NOTE:** The small stainless steel cup nests inside the large stainless steel cup. Both cups can be attached and detached from the lid by twisting.

**IMPORTANT: WASH BEFORE USE (top-shelf dishwasher safe)**

#### ASSEMBLY INSTRUCTIONS



1. Fill small stainless steel cup with water to MAX fill line and twist on lid.
2. Fill large stainless steel cup with water to MAX fill line and pour into outer plastic cup.
3. Twist the large (empty) stainless steel cup onto the lid.
4. Twist the outer plastic cup with the assembly from Step 3.

**5. Place upright in your freezer until frozen solid (minimum of 12 hours) and your Keurig® HyperChiller® is ready to use!**

#### LIMITED ONE-YEAR WARRANTY

Keurig Green Mountain, Inc. (Keurig) warrants that your Keurig® HyperChiller® Iced Coffee Chiller will be free of defects in materials or workmanship for a period of one year from the date of purchase. This warranty only applies to Keurig® HyperChiller® Iced Coffee Chiller in the United States and Canada. This warranty gives you specific legal rights, and you may also have other rights that vary from state to state and, in the case of Canada, from province to province.

#### WHAT IS NOT COVERED BY THE LIMITED WARRANTY?

THIS WARRANTY DOES NOT COVER CONSEQUENTIAL OR INCIDENTAL DAMAGES SUCH AS PROPERTY DAMAGE AND DOES NOT COVER INCIDENTAL COSTS AND EXPENSES RESULTING FROM ANY BREACH OF THIS WARRANTY, EVEN IF FORESEEABLE. This warranty does not cover damage due to improper installation, alteration, accident, or any other event beyond the control of the manufacturer. Defects or damage resulting from misuse, abuse, or negligence will void this warranty. This warranty does not cover scratching or damage that may result from normal usage. Some states or provinces do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you depending on the state or province of purchase.


#### OTHER LIMITATIONS

THIS WARRANTY IS EXCLUSIVE AND IS IN LIEU OF ANY OTHER EXPRESS WARRANTY, WHETHER WRITTEN OR ORAL. IN ADDITION, KEURIG HEREBY SPECIFICALLY DISCLAIMS ALL OTHER WARRANTIES WITH RESPECT TO YOUR KEURIG® HYPERCHILLER®, INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR ANY PARTICULAR PURPOSE. Some states or provinces do not allow disclaimers of such implied warranties or limitations on how long an implied warranty lasts, so the above limitation may not apply to you depending on the state or the province of purchase.

#### HOW DO YOU OBTAIN WARRANTY SERVICE?

Keurig® HyperChiller® Iced Coffee Chillers are high-quality accessories and, with proper care, are intended to provide years of satisfying performance. However, should the need arise for warranty servicing, simply call Keurig Customer Service at our toll-free phone number, 1-866-901-BREW (2739).

#### INSTRUCTIONS FOR DAILY USE



#### STEP 1

Brew fresh coffee directly onto the recessed area of the HyperChiller® lid with your compatible Keurig® coffee maker. Liquid will flow through the opening at the bottom of the lid and into the cooling chamber.

**NOTE: It is OK to brew over the vent on the recessed area of the lid. During use, it enables air to escape from the ice chamber, so you may see bubbles coming from it. Also, once frozen, there is no need to take the product apart for regular use.**  
**WARNING: Use caution when handling hot liquids.**

#### STEP 2

After the coffee is inside of the HyperChiller®, gently swirl the product every few seconds to keep the coffee moving.

#### STEP 3

Pour via the spout on the opposite side of the lid into the cup and enjoy!  
**NOTE: Cooling time requirements vary based on freezer temperature, initial liquid temperature & volume, as well as whether the product is swirled or not. Please refer to "Cooling Times" chart.**

#### STEP 4

To prepare for your next use, simply pour clean water through the lid (as you did with the coffee) and then pour back into the sink. Lastly, dry off condensation from the outside and put the product back in the freezer in an upright position.



## Coffeehouse taste in your own home.

### FIND YOUR PERFECT POD

With over 75 brands and hundreds of varieties, find your match at

[keurig.com/new](http://keurig.com/new)