

To turn the candle ON/OFF:

To turn the candle on without using the timer, press and release the green button on the bottom of the candle.

To turn the candle off, press and release the green button on the bottom of the candle.

To utilize the 5 hour timer function:

At the time of day you would like to have your candle turn on, look at the top of the candle and press and hold the green button for 3 seconds until you see the candle blink once. This will make it so your candle will turn on every day for 5 hours, shut off for 19 and continue this cycle daily, lighting at the exact time you set the timer.

To utilize the programmable timer:

Step 1: At the time of day you would like to have your candle turn on, press and release the green button on the bottom of the candle (do not hold the button for 3 seconds, just press and release to turn the candle on).

Step 2: While looking at the top of the candle, press and hold down BOTH of the buttons on the bottom of the candle for 6 seconds. The candle will turn off while you are holding the two buttons then start to blink after about 6 seconds.

Each time the candle blinks, you are adding 1 hour to the time the candle will be on (1 blink = 1 hour, 2 blinks = 2 hours, etc.). When the candle blinks the number of times/hours you want the candle to be on for, let go of the two buttons. Note: the candle can be programmed to stay lit from 1 – 23 hours.

To reset your timer, simply press and release the green button on the bottom of the candle. Once you have reset the timer you can follow the above instructions to re-program the candle for a different time.

For example:

To have the timer set to turn on at 6:00pm and run for 6 hours, you need to first press the green button at 6:00pm to turn the candle on. Once you see it is on, press and hold down both buttons while looking at the top of the candle. You will see the light turn off for about 6 seconds then the candle will start to blink; count 6 blinks then release both the buttons.

The candle will now be programmed to run for 6 hours starting immediately and from that point on every day it will turn on at 6:00pm and off at 12am.