



## CAUTION

This product contains small parts, which, if removed, can pose a choking hazard. Keep away from small children.

Insert battery as displayed on the battery compartment. Failure to insert the battery correctly may result in damage to your remote.

Please recycle used battery or dispose of it safely in accordance with the battery manufacturer's recommendations.

Always purchase the correct size and grade of battery most suitable for the intended use.

Remove battery from equipment if it is not to be used for an extended period of time.

Do not mix old and new batteries.

Do not mix Alkaline, Carbon-Zinc, NiMhd, or NiCad batteries.

Please recycle used batteries or dispose of them as per state and local guidelines.

Do not dispose of batteries in fire.

## FCC COMPLIANCE

NOTE: This device has been tested and found to comply with the limits for a class B digital device pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. The device generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this device does cause harmful interference to radio or television reception, which can be determined by turning this device off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the distance between this device and the receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC rules. Operation is subject to the following conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

**WARNING** Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

LUMINARA REMOTE CONTROL



# LUMINARA®

Real Flame-Effect Candle

Relax and let it glow.

1-877-90-LUMIN (58646)

[www.luminara.com](http://www.luminara.com)

® & ©2015 LUMINARA WORLD WIDE, LLC

Eden Prairie, MN 55344 USA

COVERED BY U.S. PATENT 8070319

AND OTHER U.S. AND FOREIGN

INTELLECTUAL PROPERTY

Designed by Luminara® in USA

Assembled in China



Dear Customers,

We hope that you will be delighted with the functionality of your Luminara® Candle Remote Control. For optimal performance, please take the time to read the instructions inside.

Thank you for choosing our product.



## BATTERY INSTALLATION & MAINTANENCE

- Your Luminara® remote control requires (1) CR2025 battery (included)
- When you receive your remote and prepare for first time use, you must pull the plastic tab at the bottom of the remote.
- To replace the CR2025 battery, please refer to the back of the remote for instruction



## OPERATION

**REMOTE FUNCTION:** Your Luminara® candle must be switched to the ON position for the remote to function. Your remote will not function if your Luminara® candle is in the OFF or TIMER modes.

Your Luminara remote features two buttons. On & Off.

### ON/OFF:

To turn the candle on, push the top button labeled "ON".

To turn the candle off, push the bottom button labeled "OFF".

### TIMER:

The timer function cannot be activated from the remote control.

You can use your remote to function All remote compatible Luminara® candles.

The active range for your remote to function your Luminara® candle is up to 15 feet.