
Instructions

Thank you for choosing GooLoo Mover!



Your complete GooLoo Mover set includes:




PLEASE READ ALL INSTRUCTIONS BEFORE USE.

Clean the floor before using GooLoo Mover.

Furniture without legs — Max 660 lbs


- 1. Insert Crowbar completely under corner of furniture.
- 2. Press down gently on Crowbar handle to lift furniture. (Fig. 1)
- 3. Hold Trolley by knob and insert under corner of furniture.
- 4. Point Trolley arrow in the direction of travel. (Fig. 2)
- 5. Lower furniture slowly by releasing pressure on Crowbar handle.
- 6. Repeat steps 2-6 for remaining three Trolleys.
- 7. Push furniture from a low position to roll safely across floor. (Fig. 3)

8. Remove Trolleys after moving furniture to new location.






(Fig.1)




Furniture WITH legs — Max 440 lbs

- A. Choose size and number of Rings to raise Crowbar to height of furniture.
- B. Combine rings with Cradle on top and snap Crowbar into Cradle. (Fig. 4)
- C. Position Ring Tower to insert Crowbar correctly under furniture corner. (Fig. 5)
- D. Follow steps 2-8 above.



Moving across carpeting


- E. Snap Frames to undersides of all Trolleys. (Fig. 6)
- F. Follow steps 1-8 above.
- G. Remember steps A-D above when moving furniture with legs.



Trolley

Tips for smarter moving

- If furniture sits flat on floor, push gently against it to make a gap for Crowbar. (Fig. 7)
- When moving furniture less than 220 lbs, use 3 Trolleys: 2 in front, 1 in back. (Fig. 8)
- When adding the last Trolley, use an extra Short Ring to safely position Crowbar under corner.



CAUTION:

- · Use this product only for its intended purpose.
- This product cannot be used to move up and down steps.
- · Heating or tampering with this product will damage it.
- When lifting tall furniture, be sure no one is standing nearby.
- · Do not lift furniture when hands or feet are underneath it.

GOOLOO® (Patent No. 14355822)

GooLoo Tools International Co., LTD